



Omega infrared emitters weld filter container

Housings for swimming bath filters are relatively large and thick-walled and must be pressure-resistant. They are injection-molded in two halves in polypropylene (PP) and the two halves are welded together. For one company in South East Asia, the welding together of these large and thick-walled plastic components presented a real challenge, as the filter housing, when in its operating position, was clearly visible so that the welding seam had to be optically perfect. The company formerly used a welding system with resistance heating elements in an aluminum block with a Teflon coating. The heating elements were pneumatically swiveled in and out of position. However, the PP, which flows easily when melted, tended to stick on the heating element, so that quality and speed of production could no longer meet the increased production requirements. Consequently, a more efficient solution was sought, in order to save energy. Omega infrared emitters from Heraeus provided this solution.

For his customer in South East Asia, Dr Uwe Egen of IPCW (International Plastic Welding Consultancy) in Kassel, designed and built a system, which contains one of the largest Omega infrared emitters ever manufactured. This special emitter has the shape of a Greek letter omega, a diameter of 61 cm and is fitted with a 180° gold reflector, so that the heat can be totally targeted to where it is needed.

Two of the ring-shaped emitters project their heat radiation onto the edges of the half shells. They sit in a swivel device and are swiveled away after they have melted the plastic edge. The two halves can then be joined together. An intelligent control system, which was fitted in the existing control cabinet, helps to maintain an intensity/time profile. Combined with the correct welding pressure, this ensures an optimum welded joint.

"The infrared system has replaced the contact heating elements, so that now we have much shorter cycle times," says Dr Egen. "However the main advantage of the infrared technology for me is that the two halves can be precisely centered. Infrared heats without contact, so there is no longer any possibility of contact surfaces sticking together and then shifting out of position."



Features

- Welding of filter units made of PP
- contact free heating
- Parts can be precisely centered without sticking together and shifting out of position

Technische Daten

- Omega infrared emitters
- diameter of 61cm
- 180° gold reflector

Germany

Heraeus Noblelight GmbH
Infrared Process Technology
Reinhard-Heraeus-Ring 7
63801 Kleinostheim
Phone +49 6181 35-8545
Fax +49 6181 35 16-8410
hng-infrared@heraeus.com
www.heraeus-noblelight.com/infrared

USA Heraeus Noblelight America LLC 1520C Broadmoor Blvd. Buford, GA 30518

Phone +1 678 835-5764 Fax: +1 678 835-5765 info.hna.ip@heraeus.com www.heraeus-thermal-solutions.com Great Britain
Heraeus Noblelight Ltd.
Clayhill Industrial Estate
Neston, Cheshire
CH64 3UZ
Phone +44 151 353-2710
Fax +44 151 353-2719
ian.bartley@heraeus.com
www.heraeus-infraredsolutions.co.uk

China

Heraeus Noblelight (Shenyang) LTD 2F, 5th Building 5 No. 406, Guillin Rd, Xuhui District 200233 Shanghai Phone +8621 3357-5555 Fax +8621 3357-5333 info.hns@heraeus.com www.heraeus-noblelight.cn